


## Little Charmers - Free Mylar Snowmen 054

The colors listed here are only suggestions - feel free to use the colors that you prefer. All of these designs have been sewn out several times on different machines using one layer of mesh stabilizer. We recommend Blue Opal Mylar for these designs. The first 2 colors in each design create an outline that you will cover with mylar, and then tacks the mylar down for you. We used color #3 (white) for these so that we didn't need to change thread colors too often.

For info on using mylar and where to buy it, check this link: <http://www.charmingstation.com/MylarDesigns.asp>

Some of our designs have two or more stops for the single color because the elements are either tiny and very close together or the lines of stitching would cross one another. Rather than leaving tiny jump stitches that are hard to remove, your machine will stop, tie off stitches and move to the beginning of the next element. You can just start it up again (without changing thread colors). This will make your sewout neater and will mean less trimming when you are finished.



- Color #1 White for outline  
...Cover this outline with Blue Opal Mylar
- Color #2 White (even though it says gray) for tack down stitch
- Color #3 White for snowman
- Color #4 Orange for nose, pumpkin
- Color #5 Lime Green for hat band and scarf
- Color #6 Purple for Hat
- Color #7 Dark Gray for Caldron
- Color #8 Brown for stick
- Color #9 Yellow for hat buckle
- Color #10 Blue for snowflakes
- Color #11 Black for eyes
- Color #12 Black for buckle and mouth  
...remove excess mylar by tearing back toward the stitching

1 2 3 4   
Are You a  
Good Witch  
or a  
Bad Witch?

1 2 3   
Bibbity  
Bobbity  
Boo

If you appreciate the free designs from your favorite digitizers, let your digitizer know.

The best way to say thank you

is to make a purchase - no matter how small - from that digitizer.



This text design is done with a satin stitch so you may want a medium weight stabilizer to prevent puckering.

Each line will stop at the end and tie off stitches. The machine will move to the beginning of the next line and wait for you to start up again. This allows you to change colors if you want, or to continue along with the same color.

These designs have been manually digitized and carefully tested. You have our permission to use these designs on projects for yourself, as gifts or for items for sale. Please give credit to [www.charmingstation.com](http://www.charmingstation.com) where possible. You do not have the right to give the designs to others - please ask them to go to our website and download them directly.

Please do not copy our original works or patterns. Changing them in anyway does not end our copyright.

If you have any questions, please send email to [CustomerService@CharmingStation.com](mailto:CustomerService@CharmingStation.com)

If you appreciate the free designs from your favorite digitizers, let your digitizer know.

The best way to say thank you  
is to make a purchase - no matter how small - from that digitizer.